

EACH SET INCLUDES



RUBBER TIPS

Useful for coverage while storing, quieting your poles on the trail and protecting sensitive terrain.



RUBBER FEET

Perfect for hard, flat, or rocky surfaces.



MUD BASKETS

Will help prevent trekking poles from sinking into softer, looser ground.



SNOW BASKETS

Use on deeper, softer ground like sand or snow.



VELCRO STRAPS

To hold the poles together while not in use.




PRODUCT PARTS



Soft, lightweight, adjustable, wrist straps for ultimate comfort.



Versatile grips for maximum hand comfort in a variety of weather conditions.



Ultra strong aluminum pole shaft for lightweight durability and long-lasting strength.




Easily adjusted via a single, metal fliplock, which allows the poles to always be at the ideal length.



Tethered cable design allows for compact storage and easy collapsing.



CORK GRIP



EVA FOAM GRIP

EST. 2015



USER GUIDE

Z-STYLE FOLDING TREKKING POLES

Ultra Strong, Lightweight, Compact Design



WWW.HIKERHUNGER.COM



WWW.HIKERHUNGER.COM

ADJUSTABLE HEIGHTS


Customize the height of your pole to your liking quickly and easily.

The best height for walking poles varies from user to user. It is recommended that your elbows form a 90 degree angle for the most comfortable height when standing straight and walking on a flat surface.



15" COLLAPSED

The compact design allows the poles to easily fit inside your pack or luggage when collapsed.



54" FULLY EXTENDED

FOR YOUR SAFETY

Be careful to not extend your poles past the STOP mark. This could make the poles unstable.

No trekking pole is indestructible and when excessive force is accidentally applied, they may bend or break. For example if a pole gets lodged between a rock and pushed forward, or if you bear down on them to break a fall.

Our Z-Style Folding Trekking Poles are built to withstand four-season terrain and when used properly are your best choice for lightweight, reliable stability. They are designed to be incredibly strong when force is applied from different directions. They are able to withstand a high threshold of weight and varying terrain.

WWW.HIKERHUNGER.COM

SCAN THIS CODE FOR
VIDEO INSTRUCTIONS ON
HOW TO USE YOUR POLES



SCAN ME

If you're experiencing ANY issue with your poles not locking in place, scan above for a short demo! This is a quick fix!



ADJUSTING THE STRAPS

STEP 1



Insert hand in an upward direction through the bottom of the strap.

STEP 2



Grab the grip of the pole with your hand.

STEP 3



Pull the end of the strap to tighten to fit your hand and wrist.

STEP 4



Pull the bottom of the loop to lock the strap in place.

QUESTIONS OR ISSUES?

If you have ANY product related questions or need support after using our poles, please message us through

Amazon Storefront or at
hello@hikerhunger.com
Call us: +1 406-219-1363

One of our support specialists will happily get back to you within 24 hours.

USER GUIDE

MAINTENANCE & CLEANING CARE

- After use, clean inside of pole ends with a damp rag, and wipe down each section.
- Let poles air dry.
- Store poles collapsed and folded.
- If cork or EVA foam handles are dirty, clean by gently scrubbing with a sponge and a soapy solution.
- Make sure handles are completely dry before storing.

LOCKING YOUR POLES IN PLACE

STEP 1



When your pole is hanging vertical, pull a fourth, patterned section down from the top section.

STEP 2



Continue to pull this patterned section out (harder than you think) until you see a silver button pop out. The button will pop out right below the top section.

STEP 3



Once the button pops out, your poles will be securely locked in place.

STEP 4



Use the flip lock on the top section to adjust the pole to your preferred length.

*If you are unable to get the silver button to pop out, please give us a call or watch the instructional videos on our website.